## INSTALLATION MANUAL



INSTALLATION MANUAL S MODULE

## Introduction

The S MODUL enables connection of GPS locator with original car alarms or car alarms with coded sirens, which does not have its own output.

The principle of S MODUL is very simple. Power cable of siren goes through the S MODUL and in case the siren is activated (siren is honking) the current consumption in this cable will increase. The increase of current consumption is monitored by S MODUL and on its output appears a minus impulse, which is activated by GPS locator alarm input. The GPS locator will activate INPUT alarm and the owner of the vehicle will receive an SMS with information about intrusion of the vehicle.



## Installation into the vehicle

- 1. Place the S MODUL into the vehicle in a dry place (for example under the dashboard of the vehicle).
- 2. The main core of the installation is an interruption of siren power cable and connection of siren power supply through the S MODUL. For installation follow the schema below.

